



Trailer Storage Preparation

If your trailer is to be stored for an extended period or over the winter, it is important that the trailer be prepared properly.

1. Remove the emergency breakaway battery and store inside, out of the weather. Charge the battery at least every 90 days.
2. Jack up the trailer and place jack stands under the trailer frame so that the weight will be off the tires. Follow trailer manufacturer's guidelines to lift and support the unit. Never jack up or place jack stands on the axle tube or on the equalizers.
3. Lubricate mechanical moving parts, such as the hitch and suspension parts that are exposed to the weather.

Note: On oil-lubricated hubs, the upper part of the roller bearings are not immersed in oil and are subjected to potential corrosion. For maximum bearing life it is recommended that you revolve the wheels periodically (every 2 to 3 weeks) during periods of prolonged storage.

Equine Trailering Tips courtesy of USRider Equestrian Motor Plan in cooperation with nationally respected equine trailering expert and author Neva Kittrell Scheve and veterinarian and author James M. Hamilton, DVM.



We've Got You Covered.SM

PO Box 54711 • Lexington, Kentucky 40555 • 800-844-1409

Administered by Motor Club of America Enterprises, Inc.

